

SYSTEM CONFIGURATION

Pool Lab has an Authority Level system allows different aspects of system configuration. The two main Authority Levels are USER and INST (installer).

USER gives access to:

- Setting the time and date
- Setting the filtration pump timers
- Adjusting pH and chlorine targets
- Chlorine Demand Monitor
- Recovery Mode

INST gives access to all of the above, plus:

- Setting pool and spa volumes
- Adjusting the test frequency
- Activating Pump Protection

There is also LTD, TECH and FACT levels, however adjusting settings in these modes can cause functionality to cease on the pool lab system. Neither of these should be used without specific advice and guidance from the manufacturer.

The default Authority Level is USER.

How to access INST Authority Level:


1. From the Home Screen, hold the **VIEW** button in for five seconds to enter the settings menu:



2. Use the **DOWN** button to move the asterisk to **SYSTEM CONFIG**:



3. Press **VIEW** button and the Authority menu will appear:



4. Press **VIEW**. The Authority Level will be displayed:



5. Use the **UP** or **DOWN** button to scroll to **INST**:



6. Press **VIEW** to set the Authority Level to **INST**, then use the **BACK** button to return to the main menu and adjust settings as required.

The Authority Level will automatically revert to **USER** 5 minutes after completion of settings adjustments.

See the [MENUS TUTORIAL](#) for information about adjusting the settings in **INST** mode.