

## **SETTING THE TIME AND DATE**

Time is displayed in 24-hour format. 00:00 is midnight, 12:00 is midday.

Date is displayed in day / month / year format.

Setting the correct date will allow the system to automatically adjust for daylight savings time.

The clock will continue to run for several days without power. If power is disconnected for an extended period of time, the clock may reset.

1. Press the VIEW button once from the HOME VIEW to display the TIME / DATE VIEW. The screen will look like this:



- **2.** Current time and date settings are displayed.
- 3. Press either the UP or DOWN button once to enter adjustment mode.
- **4.** The HOUR digits will be flashing to indicate adjustment mode.
- 5. Use the UP and DOWN buttons to select the correct HOUR value
- **6.** Press VIEW to switch to the MINUTES field.
- 7. Use the UP and DOWN buttons to select the correct MINUTES value
- 8. Continue this process for YEAR, MONTH, and DAY fields.
- **9.** Press VIEW to save the settings.

## **SETTING ON / OFF TIMERS**

Two separate ON / OFF time periods for the filtration pump are available. You can use either one, both or none of these depending on your requirements.


Time periods can be set to traverse midnight. Time periods can overlap, in which case they will be treated as one time period. Either or both of the timers can be disabled by setting both ON and OFF times the same. A disabled timer will show ON and OFF times as dashes: --:-

Timers are labelled #1, and #2.

The first column shows the ON time. The second column shows the OFF time.

Time period settings should be retained even after extensive periods without power.

**1.** Press the VIEW button twice from the HOME VIEW to display the TIMERS VIEW. The screen will look like this:



- **2.** Current ON / OFF times are displayed.
- **3.** Press either the UP or DOWN button once to enter adjustment mode.
- 4. The HOUR digits of ON time #1 will be flashing to indicate adjustment mode.
- **5.** Use the VIEW button to cycle to the field you need to adjust.
- 6. Use the UP and DOWN buttons to select the correct value.
- 7. When finished, use the VIEW button to cycle past the last adjustable field to save the settings.